



FOR MORE INFORMATION
CALL 13 2200
VISIT telstra.com/mobile
VISIT A TELSTRA STORE OR PARTNER

GETTING TO KNOW YOUR TELSTRA T96

TELSTRA
MOBILE
NETWORK

POWERED BY  **NEXT**

IT'S HOW
WE CONNECT



LET'S GET THIS SHOW ON THE ROAD

You must be excited about your brand new Telstra T96.

This guide will help you get to know your mobile phone as quickly and easily as possible. So you get the most out of your new Telstra T96, set aside some time to explore and play around with all the handy features. You can also download the full user guide online from zte.com.au

By the way, your Telstra T96 handset is Blue Tick approved which means it's recommended for rural and regional handheld coverage.

WHAT'S INSIDE

- 03 Let's get started
- 06 Getting connected
- 11 Making calls and messaging
- 14 Managing your contacts
- 16 Extra features
- 18 Extra bits you should know

LET'S GET STARTED

YOUR PACKAGE CONTAINS THE FOLLOWING:

- Telstra T96 handset and battery
- Telstra Pre-Paid Next G[®] SIM card
- AC charger and USB charging cable
- Headset
- Telstra Pre-Paid Welcome Guide
- This Getting Started Guide
- Manufacturer's warranty card
- Mobile Muster recycling bag

YOUR TELSTRA T96






Handy Hint

For more information on status bar icons you can refer to the full user guide online at zte.com.au

GETTING CONNECTED

1. INSERT SIM CARD

- Remove back cover using the thumb catch on the bottom left corner of the handset and gently lift off.
- Insert the SIM card with the gold chip facing down and the slanted edge on the top right as shown.




Handy Hint

You can purchase a microSD memory card to expand the memory. This device can support up to 32GB microSD cards.

2. INSERT THE BATTERY

Ensure the gold tabs on the battery are aligned with the gold pins in the battery compartment. Gently push down on the battery until it clicks into place.



3. SWITCH ON YOUR TELSTRA T96


Press and hold the red power key for three seconds to switch the mobile phone on and off.

4. ACTIVATE YOUR SIM CARD

Refer to the Telstra Pre-Paid Welcome Guide for further details on activating your SIM card.

CHARGING YOUR TELSTRA T96

- Insert the AC charger supplied carefully with the plug and socket aligned correctly as shown below:



- You will hear a sound when the charger is inserted into the handset and the display will light up.

KEYLOCK ON THE KEYPAD

- You can lock the keypad from accidental dialling by holding down the * key on the home screen until you see Keypad Locked message.
- To unlock, press the centre button and then the * key.

MAIN MENU NAVIGATION

The Main Menu is a grid of icons that are used to access key features on the phone.

- From the Home screen press the centre key to access the Main Menu.
- Using the navigation arrow keys move up, down, left or right and press the centre key to select.

SOUND AND VOLUME CONTROL

You can choose one of four sound profiles to customise with your individual preferences like adjusting volume, changing message tones and ringtones.

- Select Menu and navigate to Sound Profiles.
- Highlight General and press the left soft key to edit the sound profile settings.

Handy Hint

From the home screen you can switch the phone to silent mode by holding down the # key. A speaker symbol with a line through it will appear in the top of the screen.

To switch silent off hold down the # key until symbol disappears.

MAKING CALLS AND MESSAGING

VOICE CALLS

Making a voice call

- To make a voice call, enter the number on the keypad and press OK or the green call key to dial.

If the number already exists in your Contacts, possible matches are listed where you can use up and down arrows to select.

You can also call a number from your Contacts.

- Select Menu, navigate to Contacts and press OK.
- Use the up and down arrows to search for your contact and press the green call key to dial.

Answering an incoming call

- When you receive an incoming call press the green call key or OK to answer the call. You can press OK for loud speaker mode.
- To reject or end a call press the red end key.

TEXT MESSAGING (SMS)

Sending an SMS text message

There are two ways to access your SMS messages. You can press the right navigation key to access the shortcut for Messages. Alternatively, select Menu from Home screen and navigate to Messages.

- Create a message by selecting Create Message or pressing the number 1 key.
- In the Recipient field type in your contact number or press the centre key to select a contact from your address book.
- Press the navigation down key to move to the text field and enter your message with the letter keys on the keypad.
- When complete press the centre key to send the message.

Viewing a received text message

When you receive a text message an envelope icon will be displayed in the status bar at the top of your display. You will also be notified by a message alert tone and vibration if these settings are active.

- You can press the centre key to view the message
- Alternatively to view all messages, select Menu from the Home screen and navigate to Messages. Then select Inbox and press OK or press the number 2 key.

MANAGING YOUR CONTACTS

When you first switch your handset on you will be asked if you wish to import your contacts from your SIM card. Select Yes when prompted to import SIM contacts to the handset memory.

Handy Hint

Before you can import your contacts to your new phone, you'll need to make sure they're saved to the SIM card.

OPENING YOUR CONTACT LIST AND ADDING A NEW CONTACT

- Select Menu, navigate to Contacts and press OK.
- Open the Options menu using the left soft key, then down arrow until Add new contact is highlighted and press OK. Alternatively you can press the number 3 key.
- Enter in contact details and press Save to complete.

COPY CONTACTS FROM SIM CARD

- From your Contacts, select Options and use the down arrow until Advanced is highlighted and press OK. Alternatively you can press the number 8 key.
- Use the down arrow until (U)SIM Management is highlighted and press OK or press the number 2 key.
- Navigate to Copy contacts from (U)SIM and press OK.

EXTRA FEATURES


CONNECTING AN EXTERNAL ANTENNA

Using an external antenna may be recommended in areas of lower coverage to improve your device performance. External antennas are available from your retailer. Insert the connector carefully to avoid damage to your device.

USING A MEMORY CARD (OPTIONAL ACCESSORY)

To use the device as a portable storage drive insert a microSD card up to 32GB:

- Remove back cover using the thumb catch on the bottom right corner of the handset and gently lift off.
- Insert the microSD card as shown and press gently to click in to place.



- Replace back cover until it clicks.
- Connect the handset to your computer using the USB cable supplied and the memory card will display as an external drive.

EXTRA BITS YOU SHOULD KNOW

COVERAGE

Next G[®] coverage depends on your location, device and whether your device has an external antenna attached. Visit telstra.com/mobilebbcoverage to check if you are covered.

ACCESS THE FULL USER GUIDE

For additional information the full mobile phone user guide is available for download online at zte.com.au

The spectrum device is a trade mark of Telstra Corporation Limited ABN 33 051 775 556. [™] and [®] are trade marks and registered trade marks of Telstra Corporation Limited ABN 33 051 775 556.